



Anti Foam/ Defoamer

Instructions

**STEP
1**

- Add 3/4 ounce per BBL

**STEP
2**

- Additional material can be added.

**STEP
3**

- Sanitize to Local Codes

Sales@stone-leigh.com
Stone-Leighbrewcleaners.com
@stoneleighbrewcleaner
508-465-0230