



SL Foaming Copper CID

Instructions

Exterior Copper Vessel

STEP
1

- Check with foam application equipment for water to cleaner let down rates.

STEP
2

- Use rate 2-3 ounces per gallon of water. A higher concentration may be required depending on water hardness and soil conditions.
- Ideal temperature is 90°-135°F.

STEP
3

- Apply in 2-3-foot sections starting from the base and continue to apply higher in left to right and right to left patterns.
- Allow appropriate contact time. Do not let the foam dry.

STEP
4

- Rinse until foam is rid.

Sales@stone-leigh.com
Stone-Leighbrewcleaners.com
@stoneleighbrewcleaner
508-465-0230