



CNC Liquid

Instructions

STEP 1

- Thoroughly rinse kettle with warm water at 120-130F to remove the bulk of the soil load

STEP 2

- Dose Rate - 2 ounces per gallon ratio of Water @ 110-160F
- Circulate the alkaline solution for 15-20 minutes. Longer cycle for less

STEP 3

- Drain and thoroughly rinse with water to drain
- Follow with an acidified rinse CIP CID #1840 or #1832 @ 2 ounce per 5 Gallon to neutralize any alkaline residue and remove any beer stone films.

STEP 4

- Sanitize to Local Codes

Recommendations for Optimal Performance

Specifically designed to use in soft areas of the brewery such as the canning line

Sales@stone-leigh.com
Stone-Leighbrewcleaners.com
@stoneleighbrewcleaner
508-465-0230